

Project:	Quantity:
Model #:	Approval:

For Commercial Use Only

Instructions For Ice Thickness Adjustment& How to Restore The Original

Parameters on the Control Panel

Firstly, please kindly note: "Ice Thickness +" (here after we say "+") is the **first button** to press if you wanna restore the original parameters; However, "Ice Thickness -" (here after we say "-") is the **first button** to press if you want to adjust the ice thickness.



Original Parameters Display



"+" buttons

I . Ice Thickness Adjustment

If you want to adjust the ice thickness, process this below operation after the water flows smoothly through the evaporator:

Press "-" firstly and **hold on for around 3 seconds** until the panel display new number such as "-01" , then press "+" or "-" to adjust the ice thickness.

II . Restore The Original Parameters

Generally the original parameters is not allowed to be changed, but if customers change the numbers carelessly, please process the following steps to solve it:

1. Firstly check the display numbers as per our correct original numbers , for example model SK-500P: "220, 308 ,405, 501, 640, 708, 820, 901". If it is not same, we need to adjust the display numbers until it is same with the correct.

Here we take SK-500P as example. Adjustment operation: press "+" button, if the first number is 220, then press "+", come to display number 308, if it is not 308, now you need to press "-" to check whether it is 308, if it display the correct number 308, then we press "+" again" to come to 4-serial number, the next steps are same, just repeat it until all numbers are correct.

NOTE: Next time do not press "+" directly, because this may change the original parameters.